



Federal Aviation Administration

Subject: THUNDERSTORM



1/20/83 AC 00-24B



e. Hail.

- (1) Hail competes with turbulence as the greatest thunderstorm hazard to aircraft. Supercolled drops above the freezing level begin to freeze. Once a drop has frozen, other drops latch on and freeze to it, so the hailstone grows--sometimes into a huge iceball. Large hail occurs with severe thunderstorms with strong updrafts that have built to great heights. Eventually, the hailstones fall, possibly sane distance from the storm core. Hail may be encountered in clear air several miles from dark thunderstorm clouds.
- (2) As hailstones fall through air whose temperature is above **PC**, they begin to melt and precipitation may reach the ground as either hail or rain. Rain at the surface does not mean the absence of hail aloft. You should anticipate possible hail with any thunderstorm, especially beneath the anvil of a large **cumulonimbus.** Hailstones larger than one-half inch in diameter can significantly **damage** an aircraft in a few seconds.
- f. Icw Ceiling and Visibility. Generally, visibility is near zero within a thunderstorm cloud. Ceiling and visibility also may be restricted in precipitation and dust between the cloud base and the ground. The restrictions create the same problem as all ceiling and visibility restrictions; but the hazards are increased many fold when associated with the other thunderstorm hazards of turbulence, hail, and lightning which make precision instalment flying virtually impossible.

AC **00-424B**

g <u>Effect on Altimeters</u>. Pressure usually falls rapidly with the approach of a thunderstorm, then rises sharply with the onset of the first gust and arrival of the cold **dewndraft and** heavy rain showers, falling back to normal as the storm moves on. This cycle of pressure change may occur in **15** minutes. If the pilot does not receive a corrected altimeter setting, the altimeter may be **more** than **100** feet in error.

h. Lightning. A lightning strike can puncture the skin of an aircraft and can damage communications and electronic nawigational equipment. Lightning has been suspected of igniting fuel vapons causing explosion; however, serious accidents due to lightning strikes are extremely rare. Nearby lightning can blind the pilot rendering him momentarily unable to navigate either by instrument or by visual reference. Nearby lightning can also induce permanent errors in the magnetic examples. Lightning discharges, even distant ones; can disrupt radio communications on low and medium frequencies. Though lightning intensity and frequency have no simple relationship to other storm parameters, severe storms, as a rule, have a high frequency of lightning.

i. Engine Water Ingestion.

- (1) Turbine engines have a limit on the **amount** of water they can ingest. Updrafts are present in marry thunderstorms, particularly those in the developing stages. If the updraft velocity in the thunderstorm approaches or exceeds the terminal velocity of the falling raindrops, very high concentrations of water may occur. It is possible that these concentrations can be in excess of the quantity of water turbine engines are designed to ingest. Therefore, severe thunderstorms may contain areas of high water concentration which could result in **flameout** and/or structural failure of one or more engines.
- (2) At the present time, there is no known operational procedure that can completely eliminate the possibility of engine damage/flameout during massive water ingestion. Although the exact mechanism of these water-induced engine stalls has not been determined, it is felt that thrust changes may have an adverse effect on engine stall margins in the presence of massive water ingestion.
- (3) Avoidance of severe **storm** systems is the only measure assured to be effective in preventing exposure to this type of **multiple** engine **damage/filameout.**During an unavoidable encounter with severe storms with extreme precipitation, the best known **recommendation** is to follow the **severe** turbulence penetration procedure contained in the **approved** airplane flight manual with special emphasis on avoiding thrust changes unless **excessive** airspeed variations occur.

d//20/83

6. WEATHER RADAR.

a. Weather radar detects droplets of precipitation size. Strength of the radar return (echo) **depends** on drop size **and** number. The greater the number of drops, the stronger is the echo; and the larger the drops, the stronger is the echo. Drop size determines echo intensity to a much greater extent than does drop number. Hailstones usually are **covered** with a film of water and, therefore, act as huge water droplets giving the strongest of all echoes.

- **b.** Numerous methods have been used in an attempt to categorize the intensity of a thunderstorm. **Tb** standardize thunderstorm language between weather radar operators and pilots, the **use** of Video Integrator Processor (VIP) levels is being **promoted.**
- c. The National Weather Service (NWS) radar observer is able to objectively determine storm intensity levels with VIP equipment. These radar echointensity levels are on a scale of one to six. If the maximum VIP Levels are 1 "weak" and 2 "moderate," then light to moderate turbulence is possible with lightning. VIP Level 3 is "strong" and severe turbulence is possible with lightning. VIP Level 4 is "very strong" and severe turbulence is likely with lightning. VIP Level 5 is "intense" with severe turbulence, lightning, hail likely, and organized surface wind gusts. VIP Level 6 is "extreme" with severe turbulence, lightning, large hail, extensive surface wind gusts, and turbulence.
- **d. Thurderstorms** build and **dissipate** rapidly. Therefore, do not attempt to plan a course between echoes. The best use of ground radar information is to isolate general areas and coverage of echoes. You must avoid individual storms **from** in-flight observations either by visual sighting or by airborne radar. It is better to avoid the whole thunderstorm area than to detour around individual storms unless they are scattered.
- e. Airborne weather avoidance radar is, as its name implies, for avoiding severe weather most for penetrating it. Whether to fly into an area of radar echoes depends on echo intensity, spacing between the echoes, and the capabilities of you and your aircraft. Remember that weather radar detects only precipitation drops; it does not detect turbulence. Therefore, the radar scope provides no assurance of avoiding turbulence. The radar scope also does not provide assurance of avoiding instrument weather from clouds and fog. Your scope may be clear between intense echoes; this clear area does not necessarily mean you can fly between the storms and maintain visual sighting of them.
- f. Amember that while hail always gives a radar echo, it may fall several miles firm the nearest visible cloud and hazardous turbulence may extend to as much as 20 miles from the echo edge. Avoid intense or extreme level echoes by at least 20 miles; that is, such echoes should be separated by at least 40 miles before you fly between them. With weaker echos you can reduce the distance by which you avoid them.

AC 00-24B

7. DO'S PAND DON'S SFOR ETHUNDERS TORM FLYING.

a. Above all, remember this: never regard any thunderstorm lightly? even when radar observers report the echoes **are** of light intensity. Avoiding thunderstorms is the best policy. **Ebllowing** are sane **do's** and **don'ts** of thunderstorm avoidance:

- (1) Don't land or takeoff in the face of an approaching thunderstorm. A sudden gust front of **low** level turbulence could **cause** loss of **control**.
- (2) Don't attempt to fly under a thunderstorm even if you can see through to the other side. 'Turbulence and wind shear under the storm could be disastrous.
- (3) Don't fly without airborne radar into a cloud mass containing scattered embedded thunderstorms. Scattered thunderstorms not embedded usually can be visually circumnavigated.
- (4) **Don't** trust the visual appearance to be a reliable **indicator** of the **turbulence** inside a thunderstorm.
- (5) Do avoid by at least 20 miles any thunderstorm identified as severe or giving an intense radar echo. This is especially true under the anvil of a large exmulonimbus.
- (6) Do circumnavigate the entire area if the area has 6/10 thunder-storm coverage.
- (7) Do remember that vivid and frequent lightning indicates the probability of a severe thunderstorm.
- (8) Do regard as extremely hazardous any thunderstonm with httops
 35,000 feet or higher whether the top is visually sighted or determined by radar.
- J. J.f you cannot avoid penetrating a thunderstorm, following are same do's BEFORE entering the storm:
- (1) Tighten your safety belt, put on your shoulder harness if you have one, and secure all loose objects.
- (2) Plan and hold your course to take you through the storm in a minimum time.
- (3) To avoid the most critical icing, establish a penetration altitude below the freezing level or above the level of -15%c.
- (4) Verify that **pitot** heat is on and turn on carburetor heat or jet engine anti-ice. Icing can be rapid at any altitude **and cause** almost **instantaneous power** failure and/or loss of airspeed indication.

1/20/83 AC 00-24B

(5) Establish **power** settings for turbulence penetration airspeed **recommended** in your aircraft manual.

- **(6)** Turn **up cockpit** lights to highest intensity to lessen temporary blindness **from** lightning.
- (7) If using automatic pilot, disengage altitude hold mode and speed hold mode. The automatic altitude and speed controls will increase maneuvers of the aircraft thus increasing structural stress.
- (8) If using airborne radar, tilt the antenna up and down occasionally.

 This will permit you to, detect other thunderstorm activity at altitudes other than the one being flown.
 - **c.** Following are **some do's and don'ts** during the thunderstorm penetration:
 - (1)) Do keep your eyes on your instruments. Looking outside the mdq#t can increase danger of temporary blindness from lightning.
 - (2) Bon't change power settings; maintain settings for the recommended turbulence penetration airspeed.
 - (3) Do maintain/constant attitude; let the aircraft "ride the waves."

 Maneuvers in trying to maintain constant labitude increase stress on the aircraft.
 - (4) Don't turn back once you are in the thunderstorm. A straight course through the storm most likely will get you out of the hazards most quickly. In addition, turning maneuvers increase stress on the aircraft.

WILLIAM TO BRENNAN

Acting Director of Flight Operations

Milliam Preman

U.S. GOVERNMENT PRINTING OFFICE: 1989 0-943-154